

Flow custom

www.Flow-custom.com

Universal Compatibility Simplified Design

Before installation please
check by hand that the Pod fits
well to your mast section.
If not contact us before tight it,
we will give you a solution.

(thick leading edges can crack the
nose if it be tight)



>>> Installation Steps:



1 - Remove the 4 screws from the back of the Stator.



2 - Turn and slide down to remove the back piece.



3 - Screw the motor to the pod with the 4 m4 x 16 screws provided



4 - The exceed black heat shrink tube should be wrapped around with tape.

5 - Sharp Trailing edges can damage the pod, protect it with tape.



6 - The pod should sit on a flat section of the mast, if you want the motor higher you must cut the cable guide, we recomend to leave at least 5cm of cable guide to wrap with tape around the mast.



7 - Choose the nose for your mast Short (113-133mm chord) Long (134-160mm cord). We have included split washers to prevent the screws from loosening up and also to prevent Overtightening!! **Attention!!**

*Split washer flattened = Tight Enough
*Always hold the pod and cable with tape wrapping them around the mast.